## RXRX-AL01 and RXRX-AL02 Lockout Control

| Blink Codes | Description of Blink Code |
|---|---|
| | |
| 1 | High pressure switch of Compressor #1 opens or in lockout mode. |
| 2 | Low pressure switch of Compressor #1 opens or in lockout mode. |
| 3 | High pressure switch of Compressor #2 opens or in lockout mode. |
| 4 | Low pressure switch of Compressor #2 opens or in lockout mode. |
| 5 | Brown out AC voltage to R and C terminals below 18VAC |