SYSTEM CHARGE CHART - REFRIGERANT 410A
6 TON, CIRCUIT 1

CAUTION:
1. RETURN AIR TEMPATURE MUST BE WITHIN COMFORT CONDITIONS BEFORE FINAL, REFRIGERANT CHECK.

INSTRUCTIONS:
1. MEASURE PRESSURE AT COMPRESSORE SUCTION AND LIQUID.
2. MEASURE OUTDOOR AMBIENT TO UNIT.
3. PLACE (X) ON CHART WHERE SUCTION AND LIQUID INTERSECT.
4. IF (X) IS BELOWOUTDOOR AMBIENT LINE, ADD CHARGE AND REPEAT STEPS 1-3
5. IF (X) IS ABOVE OUTDOOR AMBIENT LINE, RECOVER EXCESS CHARGE AND REPEAT STEPS 1-3.

