

INSTALLATION INSTRUCTIONS FOR AIR HANDLER AND ELECTRIC FURNACE COMBUSTIBLE FLOOR BASE (COUNTERFLOW APPLICATIONS)



TYPICAL CROSS-SECTION



MODEL NUMBER	A
RXHB-17	18.625
RXHB-21	22.125
RXHB-24	25.625

NOTE:
ALLOW A MINIMUM OF 1" CLEARANCE AROUND HOLE FOR SEATING OF FLOOR BASE.

92-20324-06-00
H-1005S047